

Justock G3 samt Justock Handout Inställningar: Gröna rektanglar visar respektive RPM-inställning

2 Programmable Items

Those "black background and white text" options are the factory default settings.

Programmable Items	Option 1	Option 2	Option 3	Option 4	Option 5	Option 6	Option 7	Option 8	Option 9
1. Running Mode	Forward with Brake	Forward/Reverse with Brake	Forward /Reverse						
2. Drag Brake Force	0%	5%	10%	20%	40%	60%	80%	100%	
3. Cutoff Voltage	Disabled	2.6V/Cell	2.8V/Cell	3.0V/Cell	3.2V/Cell	3.4V/Cell			
4. Start Mode (Punch)	Level 1	Level 2	Level 3	Level 4	Level 5	Level 6	Level 7	Level 8	Level 9
5. Max Brake Force	25%	50%	75%	100%					
6. Max Reverse Force	25%	50%	75%	100%					
7. Initial Brake Force	= Drag Brake Force	0%	20%	40%					
8. Neutral Range	6%	9%	12%						
9. ESC Thermal Protection	Disabled	Enabled							
10. Motor Thermal Protection	Disabled	Enabled							
11. Motor Rotation	CCW	CW							
12. BEC voltage	6.0V	7.4V							
13. RPM Limit	Standard	Unlimited	25000rpm	22500rpm	20000rpm	17500rpm	15000rpm	12500rpm	
	Handout	Unlimited	47500rpm 23750rpm(4poles)	35000rpm 17500rpm(4poles)	30000rpm 15000rpm(4poles)	25000rpm 12500rpm(4poles)	22500rpm 11250rpm(4poles)	20000rpm 10000rpm(4poles)	

07 Explanations for Different Status LED

1. The throttle is in neutral zone

1) In normal Blinky mode (non-rpm limit mode), the red LED flashes rapidly.

2) In the RPM limit mode, there are two different flashing modes due to two versions of XR10-Justock G3 and XR10-Justock G3 Handout Spec, the details are as follows:
XR10-Justock G3:

In RPM limit mode, when RPM limit is 25,000, the red LED long flashes once and the green LED flashes once.

In RPM limit mode, when RPM limit is 22,500, the red LED long flashes once and the green LED flashes twice.

In RPM limit mode, when RPM limit is 20,000, the red LED long flashes once and the green LED flashes three times.

In RPM limit mode, when RPM limit is 17,500, the red LED long flashes once and the green LED flashes four times.

In RPM limit mode, when RPM limit is 15,000, the red LED long flashes once and the green LED flashes five times.

In RPM limit mode, when RPM limit is 12,500, the red LED long flashes once and the green LED flashes six times.

XR10-Justock G3 Handout Spec:

In RPM limit mode, when RPM limit is 47,500, the green LED long flashes once and the red LED flashes once.

In RPM limit mode, when RPM limit is 35,000, the green LED long flashes once and the red LED flashes twice.

In RPM limit mode, when RPM limit is 30,500, the green LED long flashes once and the red LED flashes three times.

In RPM limit mode, when RPM limit is 25,500, the green LED long flashes once and the red LED flashes four times.

In RPM limit mode, when RPM limit is 22,500, the green LED long flashes once and the red LED flashes five times.

In RPM limit mode, when RPM limit is 20,000, the green LED long flashes once and the red LED flashes six times.

Justock G3S Inställningar: Detta reglage skiljer sig i parametrar gentemot de tidigare. Detta måste utvärderas före beslut.

2 Programmable Items

Those "black background and white text" options are the factory default settings.

Programmable Items	Option 1	Option 2	Option 3	Option 4	Option 5	Option 6	Option 7	Option 8	Option 9
1. Running Mode	Forward with Brake	Forward/Reverse with Brake	Forward and Reverse						
2. Max. Reverse Force	25%	50%	75%	100%					
3. Cutoff Voltage	Disabled	2.6V/Cell	2.8V/Cell	3.0V/Cell	3.2V/Cell	3.4V/Cell			
4. ESC Thermal Protection	Disabled	Enabled							
5. Motor Thermal Protection	Disabled	Enabled							
6. BEC voltage	6.0V	7.4V							
7. Smart Fan	Disabled	Enabled							
8. Motor Rotation	CCW	CW							
9. Freewheeling	Disabled	Enabled							
10. Start Mode (Punch)	1-15 (Adjust Step:1)								
11. Neutral Range	6%	8%	10%						
12. Initial Throttle Force	1%	2%	3%	4%	5%	6%	8%	10%	12%
13. RPM Limit	Unlimited	10000RPM - 88000RPM (Adjust Step: 1000RPM)							
14. Drag Brake Force	0-100% (Adjust Step: 5%)								
15. Max.Brake Force	0%	12.5%	25%	37.5%	50%	62.5%	75%	87.5%	100%